



www.insize.com



**ISHB-B300
ALUMINUM HARDNESS
TESTER OPERATION
MANUAL**

PLEASE SCAN QR CODE TO
WATCH THE OPERATION
VIDEO OF PRODUCTS.



Introduction

Aluminum hardness tester is a kind of indentation hardness tester originally made in the USA. It has 3 models in series. ISHB-B300 is the typical model which is in widest application.

Aluminum hardness tester is mainly applied in two areas: One is Aluminum fabrication industry, to test pure Aluminum, soft Aluminum alloys, thick Aluminum alloys, Aluminum belts, and Aluminum alloys extrusions, bars, castings, forgings and assembled Aluminum alloys parts (e.g. al-alloy door&window, curtain wall etc.) Relevant standard is American standard ASTM B648-00 (Test Method for Indentation Hardness of Aluminum Alloys by Means of a Aluminum hardness tester); the other is Fiber Reinforced Plastics industry, most domestic and abroad Fiber Reinforced Plastics products are required to test Aluminum hardness. Relevant Standard is American standard ASTM D2583-07 (Test Method for Indentation Hardness of Rigid Plastics by Means of a Aluminum hardness tester) As a measuring instrument, Aluminum hardness tester has its relevant verification regulation JJG-1989 (Aluminum hardness tester). This regulation is used for verification of Aluminum hardness tester newly manufactured, under used and after maintenance. Aluminum hardness tester is smart and portable. It can be used by single hand operation, no operating experience required, can test any workpiece which is reachable in any site.

Aluminum hardness tester has following features: Wide valid testing range equivalent to Brinell hardness 25-150HBW. Used to test the hardness of all kinds of Aluminum, from very soft Aluminum to very hard Aluminum alloys. Extended application. Model ISHB-B300 is applied to test the hardness of Aluminum, Aluminum alloys, Copper, Copper alloys, Fiber Reinforced Plastics and rigid plastics etc. The improved model of it is available to test very soft metals such as lead and tin and other soft materials such as soft plastics, rubber, felt and leather etc. High sensitivity. Featured with 100 scales, much more sensitive than Aluminum hardness testers applied in Aluminum alloys industry.

No supporting required. Can test from only one side of the workpiece. No need to move or support the workpiece. Used to test super large and thick workpieces and assembly parts.

Easy conversion. The test results can be converted to HB, HR, HV and HW easily through conversion table.

Principle & Structures

Aluminum hardness tester is a kind of indentation hardness tester. It uses a special shape indenter impressed into the specimen by a standard string pressure and measures the indentation depth to obtain hardness value.

Aluminum hardness value is:

$$H_{Ba} = 100 - h / 0.0076$$

H_{Ba} ---Aluminum hardness value

h -----indentation depth (mm)

0.0076-----indentation depth for one unit of Aluminum hardness

The structure of Aluminum hardness tester is illustrated as following picture.

The main testing system of Aluminum hardness tester is set in the frame. The indenter is in the fullscale adjusting screw (indenter sleeve) with a plunger loaded by load spring on top. The test force applied on indenter by load spring through plunger is adjusted by load adjusting screw. The plunger moves up and down along with indenter, thus, the dial indicator shows hardness reading through the lever. The legs fixed at the back of the frame can insure the indenter be perpendicular to test surface. The enclosures at both left and right sides protect the inner system from being damaged and changed.

The top of indenter is 0.76mm, equivalent to 100 degrees upper on the top surface of full scale adjusting screw when the hardness tester is under non-working condition. The indicator pointed on zero at this moment.

Aluminum hardness value of the specimen. Do not impact or make the indenter slide when pressing, otherwise the indenter will be damaged. When testing softer materials, the reading will be lower down gradually. Take the reading as far as possible to remain the maximum reading result.

Calibration Of The Instrument

1 Calibration of zero point

The zero point of the instrument is stable and seldom goes wrong. If it has error, calibration of zero point should be carried out under manufacture's guide.

2 Calibration of full scale

Screw off the pivot screw, and take out the main frame from the enclosure. Then screw off the lock nut and rotate the dull scale adjusting screw with the special wrench equipped with the instrument. The readings on the dial indicator will be lower down when the nut is screwed off, on the contrary, rise up when screwed. After adjustment, screw the lock nut and re-test on the glass sheet. The indicator should point at 100 ± 1 . If there is still any error, repeat the operation above until indicator points at 100 ± 1 .

3 Calibration of the indication

Screw off the load adjusting spring. The readings on the dial indicator will be lower down when the spring is screwed off, on the contrary, rise up when screwed. Repeat the operation above until the indicator points at the hardness value of the standard hardness block.

Test on another standard hardness block. The indicator should point at the hardness value of the standard hardness block. If there is still any error, do light adjustment. Test the instrument on both "hard" and "soft" standard hardness blocks after adjustment. The readings should all point at the hardness value of the standard hardness block. If not, the indenter may be damaged, change for a new one.

Indenter

1 Protection of the Indenter

The indenter of the instrument is a accurate part made of hard steel. The point of the indenter is machined accurately to very small size. Take; care during operation to avoid any damage. When the indenter reaches to the specimen, the instrument should be pressed carefully and stable to avoid slide or scratch. The indenter will be damaged if it slides on hard material especially on rough hard material. The indenter is not in the guarantee range, so it must be treated with care. Please replace it for a new one if it is damaged. Each instrument is attached with 2 spare indenters. Purchase more from the manufacturer.

Caution!!!

Do not polish and reuse the damaged indenter!

2 Wear of the indenter

The indenter will be lightly worn after frequent use. In that case, the reading result will lead to tolerance. So the indenter should be checked frequently.

Put the instrument on the glass sheet. The indicator should point at full scale 100 ± 1 . If not, it indicates the indenter is damaged. It also indicates the indenter is damaged if the readings don't point at the hardness value of the standard hardness block when testing the instrument on the same surface.

The calibration of the instrument should be carried out if the indenter is damaged. Test the instrument on both "hard" and "soft" standard hardness blocks after adjustment. The readings should all point at the hardness value of the standard hardness block. If not, the indenter may be seriously damaged; its length can't meet the required range; change for a new one. Re-calibration should be carried out after replacing the indenter.

3 Replace the indenter

The operation process of replacing indenter is as following:

1. Screw off the screw on the enclosure.
2. Hold on the spring sleeve to make sure it can't fall down. Take

off the main frame of the instrument from the upward side of the enclosure.

3. Screw off the load adjusting screw until the cross recesses projects from the main frame.
4. Invert the instrument. Prevent the spring and plunger from falling down. Screw off the lock nut and take off the full scale adjusting screw.
5. Take off the previous indenter and put on a new one. Screw the full scale adjusting screw. Make the indenter reveal 5mm from the bottom of the frame.
6. Test on the glass sheet and take the maximum reading. Do not over load to avoid the indenter over deflecting. if the indicator exceeds 110, the dial indicator will be damaged. Adjust the full scale adjusting screw until the indicator points at 100 ± 1 .
7. Screw the lock nut. Re-inspect full scale value.
8. Inspect and calibrate the indication.
9. Re-fit on the instrument and inspect the full scale and indication.

Hardness Test Block

The instrument is attached with two hardness blocks, "high value" and "low value" which are made of aluminum and aluminum alloys.

Only the front side signed with value of the hardness block is permitted to be used. To test on both the two sides will lead to wrong readings.

Avoid to test on the point within 3mm distance from the edge and previous indentation when testing the hardness block.

The reading obtained near the previous indentation will be not accurate.

Each instrument is attached with enough hardness blocks. Spare hardness blocks can be bought from the manufacturer.

Test Time

The error of Aluminum hardness tester is bigger than Brinell hardness tester and Rockwell hardness tester. In order to reduce the test error, test for several times and take the average reading. The softer specimen is, the more test times need to be carried out. The test times should be even more when testing composite material.

The recommended test times according to different hardness value on homogeneous material and heterogeneous material are shown as following tables: Recommend test times for aluminum alloys materials:

Aluminum Hardness	Min. Test Times
50	6
60	5
70	4
80	3

Recommend test times for fiber reinforced plastics and rigid plastics:

rigid Plastics		fiber reinforced plastics	
Aluminum Hardness	Min. Test Times	Aluminum Hardness	Min. Test Times
20	9	30	29
30	8	40	22
40	7	50	16
50	6	60	10
60	5	70	5
70	4		
80	3		

Conversion

Aluminum hardness can be converted to HB, HR, HV and HW, shown as following picture and table:

a	HB 10mm 500kg	HV 5kg	HW	HR				HBa	HB 10mm 500kg	HV 5kg	HW	HR			
				B	E	F	H					B	E	F	H
35		21					32	68	60	65	11.0		71	70	94
36		22					35	69	62	67	11.4		73	72	95
37		23					37	70	64	70	11.8	17	75	74	97
38		24					40	71	67	72	12.2	23	76	75	98
39		25					42	72	69	75	12.6	28	78	77	99
40	25	26					45	73	72	78	12.9	33	80	79	100
41	25	27					47	74	75	81	13.3	38	81	80	101
42	26	28					49	75	78	85	13.7	42	83	82	102
43	27	29					51	76	80	88	14.0	47	84	83	103
44	27	30					54	77	84	92	14.3	51	86	85	104
45	28	30					56	78	87	95	14.7	55	87	86	105
46	29	31					58	79	90	99	15.0	59	89	88	106
47	30	32				23	60	80	94	103	15.3	63	90	89	106
48	30	33	0.7			26	62	81	97	108	15.6	66	91	90	107
49	31	34	1.3			28	64	82	101	112	15.9	70	92	91	108
50	32	35	1.9			31	66	83	105	117	16.2	73	94	92	109
51	33	36	2.5			34	68	84	109	121	16.4	76	95	93	109
52	34	38	3.1			36	70	85	113	126	16.7	79	96	94	110
53	35	39	3.6			39	72	86	117	131	16.9	81	97	95	111
54	37	40	4.2			41	73	87	121	137	17.2	84	98	96	111
55	38	41	4.7			44	75	88	126	142	17.4	86	99	97	112
56	39	43	5.3			46	77	89	130		17.6	88	100	98	112
57	40	44	5.8			48	78	90	135		17.8	90	101	98	113
58	42	45	6.3			50	80	91	140		18.0		102	99	114
59	43	47	6.8			53	82	92	145		18.2		103	100	
60	45	49	7.3			55	83	93			18.4		103	100	
61	46	50	7.8			57	85	94			18.6		104	101	
62	48	52	8.3			59	86	95			18.7		105	102	
63	50	54	8.8			61	88	96			18.9		106	102	
64	51	56	9.2			63	89	97			19.0		106	103	
65	53	58	9.7			65	90	98			19.2		107		
66	55	60	10.1			67	92	99			19.3		107		
67	57	62	10.6			69	93	100			19.4		108		

