



www.insize.com



**ISO-8000FN
COATING THICKNESS GAGE
(HIGH PERCISION)
OPERATION MANUAL**

PLEASE SCAN QR CODE TO
WATCH THE OPERATION
VIDEO OF PRODUCTS.



Product introduction

Coating thickness gauge is composed of the host and the probe. The host is mainly used for the display and statistics of measurement data. The probe uses digital technology, the data collection and processing is completed on the probe. According to the different substrates, one ferrous probe (included) and one non-ferrous probe have been developed (optional).

Ferrous probe

It is a magnetic probe especially used to test the ultra-thin coating thickness. The high precision and good repeatability provide an effective method for measuring the thickness of thin coatings. The coatings, varnishes, enamels, chromium, galvanized and other non-ferromagnetic coatings can be measured on magnetic substrates, especially for thin coatings on small workpieces such as screws and bolts.

Standards:

- ◆GB/T 4956-2003 Non-magnetic Coatings on Magnetic Substrates-Measurement of Coating Thickness-Magnetic Method
- ◆DIN EN ISO 2808 Paints and Varnishes-Determination of Film Thickness
- ◆JJG-818-2005 Verification Regulation of Magnetic and Eddy Current Measuring Instrument for Coating Thickness

Non-ferrous probe

The non-ferrous probe is a professional eddy current probe used to measure the ultra-thin coating thickness.

The ultra-high measurement accuracy and repeatability provide an effective method for measuring the thickness of very thin coatings. It can be used for the coating thickness measurement of non-conductive coatings such as paint, anodic oxide layer and ceramics on non-magnetic metal substrates such as copper, aluminum, die-casting zinc, brass, etc.

Standards:

- ◆GB/T 4957-2003 Non-conductive Coatings on Non-magnetic Basis Metals-Measurement of Coating Thickness-Eddy Current
- ◆DIN EN ISO 2808 Paints and Varnishes-Determination of Film Thickness
- ◆JJG-818-2005 Verification Regulation of Magnetic and Eddy Current Measuring Instrument for Coating Thickness

Technical parameters

Probe	Magnetic induction probe (included)	Eddy current probe (optional)*
Measuring range	0-500µm	0-1500µm
Resolution	0.1µm (range<100µm) 1µm (100µm≤range≤500µm)	0.1µm (range<100µm) 1µm (100µm≤range<1000µm) 0.01mm (1.00mm≤range≤1.50mm)
Accuracy	±(0.5+2%L)µm L is measuring thickness in µm	
Repeatability	≤(0.2+0.8%L)µm L is measuring thickness in µm	
Measuring mode	single and continuous	
Measuring interval	Single mode	1.5s
	Continuous mode	0.4s
Calibration mode	zero calibration and multi-points calibration (1-5 points)	
Minimum substrate thickness	0.1m	0.05mm
Minimum measuring area	Ø7mm	
Minimum radius of curvature workpieces	Convex surface	1.5mm
	Concave surface	10mm
Unit	µm / mil	
Power supply	4×1.5V AAA batteries	
Dimension	148×76×26mm	
Weight	146g	

Product advantages

1. The probe uses digital oscillation technology and high-speed ADC acquisition to ensure ultra-high stability of the gauge.
2. Ultra-small probe, especially suitable for thin coating or anodic coating measurement on small work pieces such as screws and bolts.
3. Multi-point calibration: Correct the measurement data to the standard data so as to make the measurement more accurate.
4. Statistics function: Automatically calculate the maximum, minimum, average values and standard deviation of the last 9 measured values.
5. The hardness probe ensures long-term effective use of the gauge.
6. Adopting advanced digital probe technology, digital signal processing is done directly on the probe. The probe has strong anti-jamming capacity and provides excellent accuracy. The measurement won't be affected even if the temperature change, the data remains stable. This technology ensures very good repeatability throughout the measurement process.
7. Equipped with the test stand (optional), which not only makes the measurement more convenient, but also eliminates measurement errors caused by human factors.


Operation

1. On/Off

On: Short press the power button “

Off: Long press the power button “

2. Settings and calibration



Setup/Calibration Schematic diagram

In the off state, long press the “” button for 3s or short press the “” button in the measurement mode to enter the display interface [Main Menu]. There are four sub-options, using “” “” to select [Setup / Calibration / Exit / Shutdown] and short press the “” button to confirm the selection.

2.1 Setup menu

◆Language

Short press the “” button to set the language, use “” “” to select Chinese or English. Then press the “” button to confirm the language setting.

◆Unit

Short press the “” button to set the unit, use “” “” to select μm or mil. Then press the “” button to confirm the unit setting.

◆Auto Off

Short press the “” button to set the automatically shutdown time, use “” “” to set the time from 1 to 9 minutes. Then press the “” button to confirm the shutdown time.

◆Measurement mode

Short press the “” button and enter measurement mode selection interface, use “” “” to select single-shot or continuous measurement mode, then short press the “” button to confirm.

◆Return

Short press the “” button to exit the setting mode. At the same time, the current setting will be saved and the system will return to the main menu.

2.2 Calibration menu


◆Calibration

Short press the “” button to set the calibration, use “” “” to select 1 to 5-points calibration. Then short press the “” button to confirm.

Perform zero adjustment before calibration

Due to the ambient temperature changes and different performance parameters such as magnetic and conductive properties of the material, certain measurement errors will be caused. In order to reduce the subsequent measurement error, the zero adjustment must be performed first.

Before calibration, the gauge will prompt “Zero Reference, Place Probe”, please prepare uncoated standard work piece or zero calibration plate and follow the instructions.



Zero calibration schematic diagram

When the gauge prompts “Zero Reference, Place Probe”, press the probe vertically on the center of the zero calibration plate or uncoated standard workpiece. Keep the probe stable without tilting or shaking.

After hearing the buzzer sound, the gauge prompts "Lift Probe At Least 4cm", lift the probe up to 4cm.

After hearing the buzzer sound again, the gauge prompts "Zero Check". At this time, place the probe on the Fe zero calibration plate and check the result.

Select "Rezeroing" to repeat the above zero adjustment operation; select "Exit" to quit the zero adjustment and enter the calibration operation.

Multi-point calibration

When multi-point calibration is selected, the standard films should be calibrated in order from thin to thick. The thickness between each film is more than 5 μm.


The following five-point calibration is taken as an example. It is assumed that the thickness of the five pcs of standard films are 6μm, 12 μm, 25 μm, 50 μm and 100 μm, respectively.

When measuring "pt1", select a standard film whose thickness is 6 μm and place it on the Fe zero adjustment plate or the uncoated standard workpiece for measurement. Adjust the measured value to the real thickness of 6μm by pressing "▲" "▼".

After the adjustment is completed, short press the "CAL" button to measure the "pt2". After the measurement is completed, adjust the measured value of pt2 to the real thickness.

As above, perform the calibration of "pt3", "pt4", "pt5", when the calibration of "pt5" is completed, short press the "CAL" button to enter to "Exit".

Select "Save" or "Discard" to end the calibration.



◆ Resume last calibration

In addition to the data of the current calibration data, if there is the data of the last calibration, you can view and restore by [Resume Last Calibration].

◆ Restore MFG calibration

Delete the current user calibration data and keep the current calibration data (if any) as the last calibration data.

◆ View current calibration

View the current calibration data.

◆ Return

Short press the "CAL" button to exit the calibration menu and return to the main menu.

2.3 Exit

Short press the “CAL” button to exit the main menu and switch to the measurement interface.

2.4 Shutdown

Short press the “CAL” button to turn off the gauge.

3. Measurement

- ◆ Hold the non-slip position of the probe with fingers. If you purchase the test stand, fix the probe in the rack probe fixing hole.
- ◆ Press the probe vertically on the measured object surface, keep the probe stable and do not tilt or shake, the measurement results will appear on the interface with buzzer sound.
- ◆ Lift the probe away from the measured object and then follow above step again to continue the measurement.

When measuring, the following interfaces may appear.



+INF

The measurement range is exceeded or the substrate is not a valid Ferromagnetic substrate or non-metal substrate.

-INF

The measured value is less than $-25\mu\text{m}$ and zero adjustment needs to be performed again.

- ◆ The measurement interface simultaneously displays the maximum (Max), minimum (Min), average (Avg) and standard deviation (Stdev) of the current statistics (Note: + INF and -INF will not be counted) and the number of measured data. The statistics are the last 9 valid measurement data. When there are less than 9 data, the actual number shall prevail.

- ◆ Delete statistics

In measurement mode, long press the “CAL” button for 3s to delete the currently recorded data.

- ◆ Perform zero adjustment during measurement

If there are no uncoated substrates, you can use the provided zero calibration plate to perform zero adjustment.

- 1) Short press the “CAL” button in the measurement mode, the gauge prompts “Zero Reference, Place Probe”. Then place the probe on the Fe zero calibration plate or the center of the uncoated standard workpiece, please keep the probe stable and don’t shake it.
- 2) After hearing the buzzer sound, the gauge prompts “Lift Probe At Least 4cm”.
- 3) After hearing the buzzer sound again, the LCD displays 0.0. The existing data record is cleared at the same time and the zero adjustment is completed.



If the time is out or the substrate does not meet the requirements, the gauge will prompt "Zero Reference Error".

Note: Due to workpiece surface roughness, dust, scratches, etc., the measurement data may not be displayed as 0 μm when measuring the same position after zero adjustment. The operation of the gauge must be correct and proficient, otherwise the measurement value will be unstable.

4. View Measurement Records

In the measurement mode, press the “▲” “▼” button to enter the browsing interface to view the historical data. The gauge stores a total of 9 sets of data. When the data exceeds 9 sets of data, the earliest recorded value is automatically deleted. No.1 is the earliest test data, which is pushed backward in order. Recorded data is not lost after shutting down.

When you press the “▲” button to view the data, the data record number increases from the first one.

When you press the “▼” button to view the data, the data record number decreases from the largest to the lowest. After viewing all the data, the gauge will automatically return to the measurement interface.

In the date view mode, long press the “☺” button for 3 seconds to delete the current record.

Precautions

- 1) For precision measurement, single measurement mode is the best choice because of its high stability.
- 2) During the measurement, the probe should be kept on the center of the measured point and the probe should not be suspended outside the measured surface.
- 3) Keep away from strong magnets (magnets, stereos, etc.) and strong electromagnetic fields (transformers, induction cookers, etc.) during measurement.
- 4) Before using the gauge, it is recommended to perform multi-point calibration.
- 5) Make sure that the measured object surface is clean. Dust and dirt on the measured object surface will affect the measurement accuracy.
- 6) When the gauge prompts low battery, please replace old battery with new battery.