



[www.insize.com](http://www.insize.com)



**LDS-N**  
**LASER DISPLACEMENT SENSORS**  
**Manual**



## LDS-N Series Displacement Sensor user's manual



### Warning


- 1 The light source of this product use visible laser. It is prohibited to directly or indirectly reflect the laser beam into the eyes. It may cause a risk of blindness if the laser beam enter to eyes.
- 2 This product does not have explosion-proof structure. Prohibit use inflammable, explosive gas or explosive liquid environments.
- 3 Do not disassemble or modify this product as it is not designed to automatically turn off laser emission when the product is opened. If the client disassembles or changes this product without permission, it may cause personal injury, fire, or electric shock danger.
- 4 Do not according the manual to control, adjust or operate may cause dangerous radiation leaks.

### Attention


- 1 Wiring, connecting/disconnecting interfaces, and other operations when the power is turned on are very dangerous. Please be sure to turn off the power before operation.
- 2 Installation in the following places may cause malfunctions:
  - A place full of dust or steam
  - A place where have corrosive gases
  - A place where water or oil can directly spill
  - A place with serious vibration or impact
- 3 This product is not suitable for outdoor use.
- 4 Do not use this sensor in an unstable state(eg:short time after power turned on), need about 15 minutes warm up time.
- 5 If it is necessary to use a switching power regulator, please ground the grounding terminal. Do not connect to high-voltage cables or power lines. Failure to operate will cause sensor damage or malfunction,each product in differences. Therefore, there may be slight differences in the detection characteristics of the product.
- 6 Do not use this product in water.
- 7 Please do not disassemble, repair, or modify this product without authorization, as this may result in electric shock, fire, or injury to the human body.
- 8 Clean the dust on the transmitting or receiving components to maintain correct detection. Avoid direct impact of objects on this product
- 9 Operate within the rated range.

**Warning:** This product can not be used as a safety device to protect the human body

### Panel Description




### Dimension drawing




### Circuit Diagram


#### NPN+Analog quantity



#### NPN+RS485



#### NPN




Specification

SPECIFICATION

Code	NPN	LDS-N30	LDS-N50	LDS-N100	LDS-N200	LDS-N400
	NPN+Analog	LDS-N30-MC	LDS-N50-MC	LDS-N100-MC	LDS-N200-MC	LDS-N400-MC
	NPN+RS485	LDS-N30-RS	LDS-N50-RS	LDS-N100-RS	LDS-N200-RS	LDS-N400-RS
Detection method	diffuse reflection					
Basis (center) distance	30mm	50mm	100mm	200mm	400mm	
Detection range (F.S.)	25~35mm	35~65mm	65~135mm	120~280mm	200~600mm	
Full scale	10mm	30mm	70mm	160mm	400mm	
Repeat accuracy	10μm	30μm	70μm	200μm	200~400mm: 600μm 400~600mm: 1500μm	
Linear accuracy	±0.2% F.S.					200~400mm: ±0.2% F.S. 200~400mm: ±0.3% F.S.
Temperature drift characteristics	±0.03% F.S./°C					
light	medium	red diode laser, wavelength 655nm				
source	output power	<1mW				
	laser class	IEC Class 2				
Light spot diameter		Ø50μm	Ø70μm	Ø120μm	Ø300μm	Ø500μm
Output	switch mode	NPN open collector, ≤50mA/DC 24V, residual voltage<1.5V				
	analog	analogue voltage: 0~5V (alarm: 5.2V), analogue current: 4~20mA (alarm: 0mA), Chinese display switchable				
	operation	Light.on/Dark.on selectable				
Response time	1.5ms/5ms/10ms, switchable					
Power supply	DC12~24V					
No-load current	<30mA (at supply voltage 24V DC), <60mA (at supply voltage 12V DC)					
Indicator light	output indicator: yellow, power indicator: green					
Protection circuit	reverse polarity protection/surge protection/short circuit protection					
Protection level	IP67					
Withstand voltage	AC1000V, 50/60Hz, 1min					
Vibration resistance	10~55Hz (period 1min), double amplitude 1.5mm, 2H in each X/Y/Z direction					
Impact resistance	500m/S <sup>2</sup> (approx. 50G), 3 times each in X/Y/Z direction					
Insulation impedance	50MΩ or more (DC500V megohmmeter)					
Material	cover case	aluminium alloy				
	lens	PMMA				
	guidewire	PVC (polyvinyl chloride)				
Connection	switching: lead-in type (4-pole, standard cable length 2m), analogue: lead-in type (5-pole, standard cable length 2m)					
Ambient illumination	incandescent lamp ≤ 3000lux, sunlight ≤ 20000lux					
Ambient temperature	operation: -10~45°C, storage: -20~60°C (non-freezing)					
Ambient humidity	operation: 35~85%RH, storage: 35~85%RH (non-condensing)					
Weight	85g (include cable)					


Installation Steps





Product Function Settings

A 2-point teaching

① Press the "M" button when there are no objects.




② Press the "M" key when there is an object present




③ Complete calibration. (When the difference between two times teachings is small, display deviation too small, and it is necessary to widen the difference and teach again)

B Limited teaching (In the case of small objects and backgrounds)

a With background for reference



b When detecting objects for reference




- ① Press the "M" button when in a background state or there is a detected object.
- ② With the background object as the reference, press the "▲" button to set the reference value in the sensor. When the object is detected as the reference, detecting the set value of the object after press the "▼" button
- ③ Complete calibration

C 1-point teaching (Window Compare Mode)

The method of setting upper and lower limit values is implemented instead of implementing 1-point teaching for the distance between the reference plane of the detected object. Use this function when discriminating within the upper and lower limits. In the case of implementing 1-point teaching (window comparison mode), please set the detection output setting in PRO mode to [1 point teaching (window comparison mode)] in advance.

For the setting method, please refer to the "PRO Mode Operation Instructions"



- ① Press the "M" button twice when there is an object being detected.
- ② Teaching completed.




D 2-point teaching (window comparison mode)

In the case of implementing 2-point teaching (window comparison mode), please set the detection output setting in PRO mode to [2-point teaching (window comparison mode)] in advance.

For the setting method, please refer to the "PRO Mode Operation Instructions".

When teaching, please use the detection product (P-1, P-2) with continuous distance.



- ① Press the "M" button (1st time) when there is a detected product P-1
- ② Press the "M" button (second time) while detecting product P-2
- ③ Complete calibration


E 3-point teaching (window comparison mode)

Perform 3 point (P-1, P-2, P-3) teaching, as shown in the following picture, and set the reference value 1\_SL between the 1st and 2nd times.

Set the reference value 2\_SL between the 2nd and 3rd times, and the method of setting the reference value range.

In the case of 3-point teaching (window comparison mode), please set the menu detection output setting to [3 point teaching (window comparison mode)] in advance.

After teaching, P-1, P-2, and P-3 will be automatically arranged in ascending order.



- ① Press the "M" button (1st time) when there is a detected product P-1.
- ② Press the "M" button (second time) while detecting product P-2.
- ③ Press the "M" button (3rd time) while detecting product P-3.
- ④ Complete calibration

Threshold Fine Tuning Function

Normally detection mode:

Press the "▲" or "▼" keys to directly change the threshold

Window comparison mode:

Press the "▲" or "▼" keys to directly change the threshold.

Press the "▲" and "▼" keys at same time to switch threshold 1 and threshold 2.

Zero adjustment function

Note: Zero adjustment requires setting the display mode to reverse mode in order to operate.

The zero adjustment function means the function of forcing the measured value to be "set to zero". When setting zero adjustment, there is a vertical line on the screen, as shown in the right picture:

Press the "M" and "▲" keys meanwhile to adjust the zero setting  
Press the "M" and "▲" keys meanwhile to cancel the zero adjustment



Key locking function

Press the "M" and "▼" keys meanwhile to lock the keys.

Press the "M" and "▼" keys meanwhile to unlock.

Menu setting

Press and hold the "M" button for 3 seconds in the distance display interface to enter the menu setting mode.


In menu setting mode, press and hold "M" for 3 seconds to exit menu setting mode.

In menu setting mode, stop for 20 seconds without pressing any buttons to automatically exit menu setting mode.


After enter the menu setting mode, press the "▲" or "▼" keys to switch menus up and down.

Short press the "M" key to enter the corresponding menu item


- ① Operation mode: standard, high-speed, high-precision



- ② Normally open and normally closed: Press the "M" key to enter, switch between "▲" or "▼" for selection, and press "M" to confirm.



- ③ Detection output: Normal mode, one point teaching, two point teaching, and three point teaching.




- ④ Analog selection: 0-5V, 4-20mA.




- ⑤ Tolerance: Equivalent to a fine turning adjustment of sensitivity, with a default accuracy of 0.07. It can be adjusted to the lowest level when detecting small differences.



- ⑥ External input: When selecting the corresponding function, the pink line and 0V are short circuited once;  
Zero adjustment: The current value is reset, and ± value is displayed within the range;  
Teaching: It can be used as a single press of the "M" button;  
Stop laser: The sensor stops emitting laser and not working;




- ⑦ Output timing: output delay, delayed output, single output, output extension, no timing. The default 5ms is not adjustable.



- ⑧ Display mode: Standard, reverse [changes the current detection value from "+35~-35" to "-35~+35", and the corresponding "0-5V" or "4-20mA" is reversed to "5-0V" or "20-4MA"], with an offset of ± 35 numerical values Change to 0-70.



- ⑨ Keep: The default is keep Off, and you can select keep On by pressing the up and down keys. When the current detection value reaches the maximum or minimum, the output voltage or current can be maintained. 【 A common application is to maintain 0 or 5v even after exceeding the range. 】



Communication method	RS485			
Synchronous method	asynchronous			
BAUD	9.6/19.2/38.4/57.6/115.2/256kbps			
Data length	8 bits			
Stop bit	1 bit			
Parity check	No			
04H instruction (read input register)				
1. Communication frame format				
1byte	1byte	2byte	2byte	2byte
Address code	Function code	Register address	Number of registers N	CRC code
2. Response frame format				
1byte	1byte	1byte	2N byte	2byte
Address code	Function code	bytes 2N	Register value	CRC code
3. Error frame format				
1byte	1byte	1byte	2byte	
Address code	Error code	Exception code	CRC code	

Read data						Response					
Address code	Function code	Register address	Number of register	CRC	Function Des	Address code	Function code	Register address	Number of register	CRC	Response Des
0x01	0x04	0x0000	0x0002	0x71CB	Obtain - distance	0x01	0x04	0x02	0x04		
0x01	0x04	0x0001	0x0001	0x600A	Obtain - operation mode	0x01	0x04	0x02	0x0000	0xB930	high-precision standard
									0x0001	0x78F0	standard
									0x0002	0x38F1	high-speed
0x01	0x04	0x0002	0x0001	0x900A	Obtain - NO/NC	0x01	0x04	0x02	0x0000	0xB930	NO
									0x0001	0x78F0	NC
									0x0000	0xB930	normally detection
0x01	0x04	0x0003	0x0001	0xC1CA	Obtain - detection output	0x01	0x04	0x02	0x0001	0x78F0	1-point teach
									0x0002	0x38F1	2-point teach
									0x0003	0xF931	3-point teach
0x01	0x04	0x0004	0x0002	0x300A	Obtain - Tolerance	0x01	0x04	0x04	0x0000	0xB930	tolerance
									0x0001	0x78F0	zero adjustment
0x01	0x04	0x0005	0x0001	0x21CB	Obtain - external input	0x01	0x04	0x02	0x0001	0x78F0	teaching
									0x0002	0x38F1	stop laser
									0x0000	0xB930	Untimed
0x01	0x04	0x0006	0x0001	0xD1CB	Obtain - output timing	0x01	0x04	0x02	0x0001	0x78F0	output extension
									0x0002	0x38F1	delay output
									0x0003	0xF931	single output setting time
0x01	0x04	0x0007	0x0001	0x800B	Obtain - output timing time	0x01	0x04	0x02	0x0000	0xB930	Normally
									0x0001	0x78F0	Reverse
0x01	0x04	0x0008	0x0001	0x8008	Obtain - display mode	0x01	0x04	0x02	0x0002	0x38F1	Offset
									0x0000	0xB930	keep On
0x01	0x04	0x0009	0x0001	0xE1C8	Obtain - keep	0x01	0x04	0x02	0x0001	0x78F0	keep OFF
									0x0000	0xB930	time screen off
0x01	0x04	0x000A	0x0001	0x11C8	Obtain - screen off selection	0x01	0x04	0x02	0x0001	0x78F0	Normally on
0x01	0x04	0x000B	0x0002	0x0009	Obtain zero adjustment value	0x01	0x04	0x04			adjustment value
0x01	0x04	0x000C	0x0002	0xB1C8	Obtain - threshold 1	0x01	0x04	0x04			threshold 1
0x01	0x04	0x000D	0x0002	0xE008	Obtain - threshold 2	0x01	0x04	0x04			threshold 2
0x01	0x04	0x000E	0x0002	0x1008	Obtain - BAUD	0x01	0x04	0x04	0x000012C0	4800	
									0x00002580	9600	
									0x00009600	38400	
									0x0001C200x	115200	
									0x0003E800	256000	

0x01	0x10	0x0003	0x0001	0x02	0x0001	0x67A3	1-point teach	0x01	0x10	0x0003	0x0001	0xF1C9
						0x0002	0x27A2					
						0x0003	0xE662					
0x01	0x10	0x0004	0x0002	0x04			tolerance	0x01	0x10	0x0004	0x0002	0x4008
0x01	0x10	0x0005	0x0001	0x02	0x0000	0xA605	zero adjustment	0x01	0x10	0x0005	0x0001	0x11C8
						0x0001	0x67C5					
						0x0002	0x27C4					
						0x0000	0xA636					
						0x0001	0x67F6					
0x01	0x10	0x0006	0x0001	0x02	0x0002	0x27F7	output extension	0x01	0x10	0x0006	0x0001	0xE1C8
						0x0003	0xE637					
0x01	0x10	0x0007	0x0001	0x02	0x0000	0xA718	Normally	0x01	0x10	0x0007	0x0001	0xB008
						0x0001	0x66D8					
						0x0002	0x26D9					
0x01	0x10	0x0008	0x0001	0x02	0x0000	0xA6C9	Reverse	0x01	0x10	0x0008	0x0001	0x800B
						0x0001	0x6709					
						0x0000	0xA6FA					
0x01	0x10	0x0009	0x0001	0x02	0x0001	0x673A	keep On	0x01	0x10	0x0009	0x0001	0xD1C8
						0x0000	0xA6FA					
						0x0001	0x673A					
0x01	0x10	0x000A	0x0001	0x02	0x0000	0x66EB	keep OFF	0x01	0x10	0x000A	0x0001	0x21C8
0x01	0x10	0x000B	0x0001	0x02	0x0001	0x66EB	time screen off	0x01	0x10	0x000B	0x0001	0x700B
0x01	0x10	0x000C	0x0002	0x04			Normally on	0x01	0x10	0x000C	0x0002	0x81C8
0x01	0x10	0x000D	0x0002	0x04			zero adjustment-	0x01	0x10	0x000D	0x0002	0xD00B
							current detection value					
							threshold-up					
							threshold					
							threshold-down					
							threshold					
0x01	0x10	0x000E	0x0002	0x04	0x000012C0	0x7ED3	4800	0x01	0x10	0x000E	0x0002	0x200B
					0x00002580	0x6913	9600					
					0x00009600	0x1D83	38400					
					0x0001C200	0x7283	115200					
					0x0003E800	0xCC23	256000					
0x01	0x10	0x000F	0x0001	0x02	0x0000	0xA6AF	reset	0x01	0x10	0x000F	0x0001	0x31CA

10H Instruction (Write Multiple Holding Registers)

1. Communication frame format

1byte	1byte	2byte	2byte	1byte	N*2 byte	2byte
Address code	Function code	Register address	Number of registers N	bytes 2N	Register value	CRC code

2. Response frame format

1byte	1byte	2byte	2byte	2byte
Address code	Function code	Register address	Number of registers N	CRC code

3. Error frame format

1byte	1byte	1byte	2byte
Address code	Error code	Exception code	CRC code

Operation Function							Response					
Address code	Function code	Register address	Number of register	Number of bytes	Register value	CRC	Function setting	Address code	Function code	Register address	Number of register	CRC
0x01	0x10	0x0000	0x0001	0x02	0x0000	0xA650	Discontinuous output	0x01	0x10	0x0000	0x0001	0x01C9
					0x0001	0x6790	Continuous output					
					0x0000	0xA781	high-precision					
0x01	0x10	0x0001	0x0001	0x02	0x0001	0x6641	standard	0x01	0x10	0x0001	0x0001	0x5009
					0x0002	0x2640	high-speed					
					0x0000	0xA7B2	NO					
0x01	0x10	0x0002	0x0001	0x02	0x0001	0x6672	NC1	0x01	0x10	0x0002	0x0001	0xA009
					0x0000	0xA663	normally detection					