



# INSTRUCCIONES DE FUNCIONAMIENTO

## Medidores de soldadura en ángulo




4836-1



4836-2

Medición:



| Código | Talla                                                                                                                                                           | Precisión         |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| 4836-1 | 3mm, 4mm, 5mm, 6mm, 8mm, 9mm, 10mm, 11mm, 12mm, 14mm, 16mm, 19mm, 22mm, 25mm                                                                                    | ±0.5mm            |
| 4836-2 | 1/8" (3.2mm), 3/16" (4.8mm), 1/4" (6.4mm), 5/16" (7.9mm), 3/8" (9.5mm), 7/16" (11.1mm), 1/2" (12.7mm), 5/8" (15.9mm), 3/4" (19.1mm), 7/8" (22.2mm), 1" (25.4mm) | ±0.02"<br>(0.5mm) |

MN-4836-ES

V1