




OPERATION INSTRUCTION

Magnification Glass

Attention:For safety, please be sure not to view the sun with magnifier.

Code	Lens number	Magnification
7523-3D5	5	1X, 1.5X, 2X, 2.5X, 3.5X




- 1-lens
- 2-Led light
- 3-Power switch
- 4-Battery cover


- 5-Handle
- 6-Rotating shaft
- 7-Bracket
- 8-Lens rotating shaft
- 9-Head hand

1. This product is suitable for various usage scenarios such as reading, painting, handicrafts, electronic maintenance, etc.


2. Preparation before use:



Open battery cover and put three AAA batteries inside






Choose the appropriate lenses as needed



Replace with a head band as needed

3. Operation:



4. Attention:

- Please do not put it under the sun to prevent fire.
- For safety, please be sure not to view the sun with magnifier.
- For any dirt on the eyeglasses, please wipe the eyeglasses gently with soft cloth like eyeglasses cloth.
- Please do not wipe the magnifier with the liquid such as banana oil, alcohol, petroletc.

MN-7523-C/E

V0